


Firmware Upgrade Procedure

1. Save the downloaded firmware file (.zip) to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
 - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the router's configuration page (default URL: <http://tew-811dru> or default IP is 192.168.10.1)
4. Navigate to the **Administrator** section and select **Upload Firmware** option.



The screenshot displays the web interface of a Trendnet AC1200 Dual Band Wireless Router (TEW-811DRU). The interface is dark-themed with a sidebar on the left containing navigation options: Wizard, Network, Wireless 2.4GHz, Wireless 5GHz, Advanced, and Administrator. The Administrator section is expanded, showing sub-options like Management, Upload Firmware, Settings Management, File Sharing, Time, System Log, Status, and IPv6 Status. The main content area is titled 'Upgrade Firmware' and includes a warning: 'Upgrade the firmware to obtain new functionality. It takes about 1 minute to upload & upgrade flash and be patient please. Caution! A corrupted image will hang up the system.' Below this is a form titled 'Upload Firmware' with a 'Location' label, an empty text input field, and a 'Browse...' button. At the bottom of the form are 'Apply' and 'Cancel' buttons. The footer of the page reads '© Copyright 2013 TRENDnet. All Rights Reserved.'

5. Click **Browse** and select firmware file (.bin) from the extracted files and click the **Apply** button to start the firmware upgrade process.
6. Wait until the firmware upload has completed and the device reboots.
7. The firmware upgrade is complete.